



How to Install the Fog, Driving, and Headlight Protective Films

- 1) Remove the black outer trim from around the fog and driving lights. There is no trim that needs to be removed around the headlights.
- 2) Clean the fog or driving light lens that you are going to cover. No insects or debris can be on the glass or the protective film may not stick.
- 3) Test-fit the protective film to the lens by just holding it up to the light. Leave the backing on for this. If there any corrections to the shape you'd like to make, do it now with a scissors.
- 4) Flood the lens with a Windex or similar glass cleaning product.
- 5) Peel off the backing and place it on the lens. The glass cleaner you sprayed on the lens will allow the film to float so you can move it around a it to get it exactly where you want it.
- 6) When it is located as you like, use the squeegee supplied to push out the fluid from under the film.
- 7) Allow the film to dry before driving the car. You can accelerate drying by turning on the fog lights or headlights if you wish.

Enjoy!

928 Motorsports, LLC