



## Installing the 928 Motorsports Ride Height Collars on Koni Red Shocks



Be sure to clean the Koni and remove any stickers or adhesive on the shock before proceeding. Your installation will go better if the outside of the shock is very smooth and clean.



**Step 1: Freeze the Koni**



**Step 2: Heat Sleeve in Oven to 450F**

