

Wiring Harness Installation Instructions

Your new engine wiring harness has been made with the finest materials available, solid copper wire, hi-temp insulation, silicone impregnated fiberglass sleaving, and genuine Porsche connectors and metric fasteners.

For you convenience, we have also tagged each connector with temporary paper labels.

These labels are designed to be removed by you or your mechanic – they will just tear off and leave little or no residue. They should not be left in place after the installation as the labels themselves are combustible.

Enjoy your 928!

Carl

Carl Fausett, 920-485-0928 carl@928motorsports.com