



928 Motorsports Maintenance Series

Copyright 2015, 928 Motorsports, LLC All Rights Reserved

Repairing the Rear Camber Pockets with the 928MS Steel Camber Pocket Liners



This is typical of the damage to the aluminum you will find on the rear crossmember of a 928.

Especially if the 928 has been driven hard, or fitted with wide tires, or both.





928 Motorsports Maintenance Series

Copyright 2015, 928 Motorsports, LLC All Rights Reserved



You will want a Dremel tool, or a Roto-Zip, a DynaFile, or just a flat-faced burr in a die grinder like this:






928 Motorsports Maintenance Series


Copyright 2015, 928 Motorsports, LLC All Rights Reserved

Put the 928 up in the air safely. You will be working under it.

Remove the rear Camber eccentric bolts and nuts. The weight of the vehicle will need to be off the tires for you to do this.



Place the steel camber pocket insert in position, and mark the sides with a pen



This is how much aluminum you will need to remove to fit the steel camber pocket

It's just a little from each side



928 Motorsports Maintenance Series


Copyright 2015, 928 Motorsports, LLC All Rights Reserved

Installing with crossmember in the car




Step 1
Remove the aluminum needed
to insert the steel camber pocket

g with crossmember in the car



Step 2
Insert the steel camber pocket

Installing with crossmember in the car



Step 3
Insert the camber eccentric.
Adjust the camber as desired.

© Copyright 2015 928 Motorsports, LLC.
All rights reserved.



928 Motorsports Maintenance Series

Copyright 2015, 928 Motorsports, LLC All Rights Reserved


OPTIONAL: Pinning the rear camber eccentric in place

If you really hit the corners hard with wide, sticky tires, you'll find that the lateral force is great enough to turn the camber eccentrics in their pockets no matter how hard you tighten the nut.

For example, I would go out at -2 deg negative rear camber, and in a couple laps be at -3.5 degrees camber.

The answer was to drill and pin the eccentric. Can be done on the car.

Gather up a M6 tap and the drill for it, and a small M6 fastener like the one shown below. A center-punch will also help. Set your rear camber the way you want it and tighten the nut on the other side as per the WSM. Mark the eccentric for drilling with the punch, and drill through the eccentric, the steel liner, and into the aluminum. Tap the hole. Insert your M6 fastener with some Loctite on the threads—done!



OPTIONAL: here on this race car we took the additional step of setting the Camber, and drilling and pinning the eccentric so the camber does not change under load.